

## Combined interior satin varnish system (all wood types)

### General surface preparation

Make sure that the wood is dry and degreased. Oily, resinous types of wood, like pine and Oregon Pina must be well degreased before varnish or stain is applied. Wipe down the wood with Epifanes Spraythinner for Paint & Varnish or denaturated alcohol and allow to evaporate. Sand the wood to a fresh surface with dry abrasive paper P60-80. Subsequently sand with finer grits from P100 to P220. Always sand along the wood grain. Remove all sanding dust and degrease once more. Allow to fully evaporate before applying varnish or stain.

### General surface preparation of tropical wood

Make sure that the wood is dry and thoroughly degreased. Moisture content must not exceed 17%. Wipe down the wood with Epifanes Thinner for PP varnish Extra, acetone or other aggressive degreaser and allow to evaporate. Use multiple (paper) towels and turn them regularly. (Do not use water!). Sand the wood to a fresh surface with dry abrasive paper P60-80. Subsequently sand with finer grits from P100 to P220. Always sand along the wood grain. Remove all sanding dust and degrease once more. Allow to fully evaporate before applying varnish.

### Products: Epifanes PP Varnish Extra + Epifanes Rubbed Effect Varnish



+

### Combined interior satin varnish system (all wood types)

After surface preparation:	Step 1	Step 2	Step 3
<b>Product</b>	<b>EPIFANES PP Varnish Extra</b>	<b>EPIFANES PP Varnish Extra</b>	<b>EPIFANES Rubbed Effect Varnish</b>
<b>Number of coats</b>	2	2 or more	3
<b>Thinner</b>	EPIFANES Thinner for Epifanes PP Varnish Extra	EPIFANES Thinner for Epifanes PP Varnish Extra	EPIFANES Brushthinner PV
<b>Percentage</b>	25%	0-5%	0-5%
<b>Drying time @ 18°C</b>	2-3 hours	2-3 hours	24 hours
<b>Abrasive paper</b>	P220 dry	P220 - dry	P400 - wet
<b>Remarks</b>	For varnish penetration inside the wood fibre, apply this 1st. coat 25% thinned. Allow 2nd. Coat 24 hours to cure and sand 2nd. Coat	These are building and grain filling base coats. Depending on the open structure of the wood, more coats may be necessary. Intercoat sanding is optional (P220-280). Always sand final coat PP Varnish Extra with P280 before going to step 3.	Lightly sand between these one-component satin coats by hand along the wood.

W. Heeren & Zoon BV  
Postbus 166  
1430 AD Aalsmeer  
tel. 0297 -360366  
info@epifanes.nl